

## Installation av terrazzoplattor

SE:

Våra terrazzoplattor består av ca 90% krossad marmor. Vid installation av dessa bör man vara medveten om att materialet drar fukt från limmet. Du bör därför använda en snabbtorkande lim. Om du använder ett långsamt torkande lim finns risk för att golvplattor böjer sig och limmet lossar längs kanten av plattan. Resultatet är att golvplattor delvis kommer att släppa från underlaget.

Stora golvplattor måste vara "dubbellimmade", ett skikt lim på golvet och ett skikt på baksidan av golvplattor.

Vi rekommenderar fix/fästmassa med följande elasticitetsklass:

- Italian Style:  $\leq 400 \times 400$ mm = C2 S1.
- Italian Style:  $> 400 \times 400$ mm = C2 S2.
- Herrljunga XQ, Italian XQ och Iberian XQ = C2 S1

Följande är viktigt att tänka på när man ska välja fix:

- Bruksanvisningen gäller för torra områden.
- Temperaturen hos underlaget eller i luften inte bör vara mindre än 5°C.
- Var noga med att mäta vatten
- Det måste vara helt täckt med lim på plattan, 60x60cm eller större plattor bör "dubbellimmas"
- Låt plattorna ligga i rumstemperatur innan installation.

## Installation of terrazzo tiles

EN:

Our floor tile is made up of approximately 90% crushed marble. When installing marble tiles and marble based floor tiles should be aware that the material draws moisture from the glue. You should therefore use fast drying glue. If you use slow drying glue is a risk that the floor tiles bend and loosen the glue along the edge of the plate. The result is that the floor tiles will be partially solved without gluing to the substrate.

Large floor tiles must be "double bonded", one layer glue on the floor and one layer on the back of the floor tile. We usually recommend adhesive with elasticity classification:

- Italian Style:  $\leq 400 \times 400$ mm = C2 S1.
- Italian Style:  $> 400 \times 400$ mm = C2 S2.
- Herrljunga XQ, Italian XQ och Iberian XQ = C2 S1

The following are important to consider when installing fix whatever you choose:

- instructions apply to dry areas.
- The temperature of the substrate or in the air should not be less than 5°C.
- Be sure to measure water
- It must be fully covered with adhesive under the tiles - 60x60cm or larger tiles will "double bonded"
- Keep the tiles lying at room temperature before the installation.