

## Installation av terrazzoplattor

SE:

Våra terrazzoplattor består av ca 90% krossad marmor. Vid installation av dessa bör man vara medveten om att materialet drar fukt från limmet. Du bör därför använda ett snabbtorkande fix. Om du använder ett långsamt torkande fix finns risk för att golvplattor böjer sig och fästmassan lossar längs kanten av plattan. Resultatet är att golvplattor delvis kommer att släppa från underlaget.

Vi rekommenderar fix/fästmassa med följande elasticitetsklass:

- Italian Style: ≤400x400mm = C2 S1.
- Italian Style: >400x400mm = C2 S2.
- Herrljunga XQ, Italian XQ och Iberian XQ = C2 S1

Följande är viktigt att tänka på vid fix och fog:

- Bruksanvisningen gäller för torra områden.
- Temperaturen hos underlaget eller i luften inte bör vara mindre än 5°C.
- Var noga med att mäta vatten
- Det måste vara helt täckt med fix/fästmassa på plattan, 600x600mm eller större plattor bör "dubbellimmas"
- Låt plattorna ligga i rumstemperatur innan installation.
- Fogens storlek bör vara minst 2-3mm. Vid plattor av format ≥600x600 ska fogen ökas med 1-2mm.

## Installation of terrazzo tiles

EN:

Our floor tile is made up of approximately 90% crushed marble. When installing marble tiles and marble based floor tiles should be aware that the material draws moisture from the glue. You should therefore use fast drying glue. If you use slow drying glue there is a risk that the floor tiles bend and loosen the glue along the edge of the plate. The result is that the floor tiles will be partially detached from the substrate. We usually recommend adhesive with elasticity classification:

- Italian Style: ≤400x400mm = C2 S1.
- Italian Style: >400x400mm = C2 S2.
- Herrljunga XQ, Italian XQ och Iberian XQ = C2 S1

The following are important to consider when installing fix and joint:

- instructions apply to dry areas.
- The temperature of the substrate or in the air should not be less than 5°C.
- Be sure to measure water
- It must be fully covered with adhesive under the tiles - 600x600mm or larger tiles will "double bonded"
- Keep the tiles lying at room temperature before the installation.
- The size of the joints should be at least 2-3mm. For tiles ≥ 600x600 the joints increase with 1-2mm.